

Einbauanleitung

Innenraumfilter

Fitting instructions

Cabin air filter

Istruzioni di montaggio

Filtro abitacolo

Notice de montage

Filtre d'habitacle

Instrucciones de montaje

Filtro de habitáculo

Monteringsanvisning


Kupéfilter

BMW 5er Serie (E39) 04.96 →

21651882 / CC1022 / MC 530-2

21651897 / CP1022 / MP 030-2

1.



2.

