



Anziehvorschrift für Zylinderkopf	219.580	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
	passend für / suitable for adaptable à / adaptable a	
	VW / Audi / Skoda	

Schraubenkopf / Head shape Anziehrefolgen/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



527.770
M 12x206x1,75



Anziehen/ * 30 Nm
Tightening/ 90 Nm
Serrage/ ➤ 90°
Apriete ➤ 90°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

1,4 TDI 3 Zyl. 2 Loch 1,63mm

Mot: CUSA, CUSB, CUTA,
CYZA, CYZB
55-77 KW (75-105 PS)

Polo, Al, Fabia

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

219.580