



<b>Anziehvorschrift für Zylinderkopf</b>	<b>340.310</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
	passend für / suitable for adaptable à / adaptable a	<b>Porsche</b>

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



872.290  
M 12x1,5x140

Anziehen/	*	5 Nm
Tightening/		50 Nm
Serrage/	□	4 Nm
Apriete		12 Nm
	➤	65°
	➤	65°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

✚ 1,64 mm, Ø 104,3 mm, Cyl. 1-3

Mot.: MA1.71/75/76, MDA.BA, MDB.CA, MDG.GA  
MDH.NA 3,8 ltr./4,0 ltr.

911 Turbo (997/991), 911 GT2/GT3 (991)

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*340.310\***