



<b>Anziehvorschrift für Zylinderkopf</b>	<b>350.231</b> passend für / suitable for adaptable à / adaptable a <b>Audi</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



Anziehen/ \* 40 Nm  
Tightening/ 60 Nm  
Serrage/ ➤ 90°  
Apriete ➤ 90°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

71 mm Ø, 1,74/1,65 mm ÷

0,9 Ltr. Mot.HA/Saugsystem abgasbeheizt

Derby, Polo 29 kW (40 PS)      07/1976>07/1979

ab Chassis 867 2300 001>

Derby, Polo 29 kW (40 PS)      08/1979>07/1983

ab Chassis 86 A 0014 601>

1,1 Ltr. Mot.HB,HC,HD/Saugsystem abgasbeheizt

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*350.231\***