



Anziehvorschrift für Zylinderkopf	471.740	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
passend für / suitable for adaptable à / adaptable a	Chevrolet/Daewoo	

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



356.390
M10x1,25x166



Anziehen/	*	Pos. 1-10: 25 Nm
Tightening/	➤	Pos. 1-10: 70°
Serrage/	➤	Pos. 1-10: 70°
Apriete	➤	Pos. 1-10: 50°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 80 mm; $\frac{\pi}{8}$: 0,55 mm

Mot: F14D3, F16D3
1.4 ltr-1.6 ltr

Chevrolet Aveo, Cruze, Kalos, Lacetti, Nubira
Daewoo Kalos, Lacetti, Nubira

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

471.740