



Einbauhinweis/installation instruction VW Passat B6 2006 - 2011

Vorne links/Front left (OE Ref. No. 3C1 837 461F)

