



<b>Anziehvorschrift für Zylinderkopf</b>	<b>550.570</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
passend für / suitable for adaptable à / adaptable a		<b>Daewoo / Chevrolet</b>

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



Anziehen/ \* 25 Nm  
Tightening/ ➤ 70°  
Serrage/ ➤ 70°  
Apriete ➤ 50°

**Zeichenerklärung / Explanations / Explication / Explicacion**

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Chevrolet  
MC:F14D3+F16D3 69-80 KW  
Lacetti, Nubira, Kalos 1.4 ltr.+1.6 ltr.16V: 03.0  
Optra 1.6ltr.: 08.03-  
Daewoo  
MC: F14D3 + F16D3 69-77 KW  
Gentra 1.4 ltr. SR: 05.03 - 04.05  
Gentra 1.4 ltr. + 1.6 ltr. E-Tec LS: 05.05-

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*550.570\***