



<b>Anziehvorschrift für Zylinderkopf</b>	<b>590.480</b>	 Das Original
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



Anziehen/ Tightening/ Serrage/ Apriete	*	M11 1-8 / 45 lb-ft M11 1-8 / 65 lb-ft M11 1-8 / 65 lb-ft	*	M11 1-8 / 60 Nm M11 1-8 / 90 Nm M11 1-8 / 90 Nm
	➤	M11 1-8 / 90° M8 9 / 10 lb-ft M8 9 / 15 lb-ft M8 9 / 25 lb-ft	➤	M11 1-8 / 90° M8 9 / 12 Nm M8 9 / 20 Nm M8 9 / 35 Nm

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Chrysler Town & Country 2010-2004 3.3L V6 201cid  
Dodge Caravan 2007-2004 3.3L V6 201cid  
Dodge Grand Caravan 2010-2004 3.3L V6 201cid

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*590.480\***