



Anziehvorschrift für Zylinderkopf	724.510	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
	passend für / suitable for adaptable à / adaptable a	Citroen, Peugeot, Fiat Lancia

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



Anziehen/ * 15 Nm
Tightening/ 50 Nm
Serrage/ □ 20 Nm
Apriete ► 285° ± 5°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
►	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 85,5 mm; ɸ: 1,40 mm

Mot: EW10J4, EW40J4S, EW10D, DEW10J4,
RFK, RFN, RFR, RLZ
2,0 Ltr. 99-130 kW (135-177 PS)

C4, C5, C8, Evasion, Jumpy, Xsara, Scudo, Ulysse,
Phedra, Zeta, 206, 307, 406, 407, 607, 806, 807

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

724.510