

PHOTOS



APPLICATIONS

AUDI

A3 (96-03) (8L1) - 1.9 TDI	90 ch	09.1996 > 07.2001
	90 ch	09.1996 > 07.2001

SEAT

LEON (98-06) (1M1) - 1.9 TDI	90 ch	11.1999 >
	90 ch	11.1999 >
TOLEDO (99-06) (1M2) - 1.9 TDI	90 ch	04.1999 > 05.2006
	90 ch	04.1999 > 05.2006

SKODA

OCTAVIA (96-10) (1U2) - 1.9 TDI	90 ch	09.1996 >
	90 ch	09.1996 >
OCTAVIA (96-10) Combi (1U5) - 1.9 TDI	90 ch	07.1998 >
	90 ch	07.1998 >
OCTAVIA (96-10) Combi (1U5) - 1.9 TDI 4x4	90 ch	11.1999 > 09.2000
	90 ch	11.1999 > 09.2000

VOLKSWAGEN

BORA (1J2) - 1.9 TDI	90 ch	10.1998 > 06.2001
	90 ch	10.1998 > 06.2001
BORA (1J2) - 1.9 TDI 4motion	90 ch	02.1999 > 06.2001
	90 ch	02.1999 > 06.2001
BORA Break (1J6) - 1.9 TDI	90 ch	05.1999 > 06.2001
	90 ch	05.1999 > 06.2001
GOLF (97-05) (1J1) - 1.9 TDI	90 ch	10.1997 > 05.2004
	90 ch	10.1997 > 05.2004
GOLF (97-05) (1J1) - 1.9 TDI 4motion	90 ch	07.1998 > 04.2002
	90 ch	07.1998 > 04.2002
GOLF (99-05) Break (1J5) - 1.9 TDI	90 ch	05.1999 > 05.2006
	90 ch	05.1999 > 05.2006
GOLF (99-05) Break (1J5) - 1.9 TDI 4motion	90 ch	05.1999 > 04.2002
	90 ch	05.1999 > 04.2002

