

## DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	Sans
Restriction du fabricant	MITSUBISHI
Type de turbo	Simple
Accessoires	sans joints

## PHOTOS



## DOCUMENTS

BT-183 Instructions de montage turbos (AST)

## APPLICATIONS

<b>MITSUBISHI</b>		
L 200 (96-06) (K__T) - 2.5 TD 4x4 (K74T)	99 ch	06.1996 >
PAJERO (91-99) (V2_W, V4_W) - 2.5 TD (V24C, V24W)	99 ch	12.1990 > 04.2000
PAJERO (91-99) Canvas Top (V2_W, V4_W) - 2.5 TD (V24C, V24W)	99 ch	12.1990 > 04.2000
PAJERO SPORT (96-08) (K90) - 2.5 TD	99 ch	11.1998 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.