

DONNEES TECHNIQUES

| | |
|--------------------------|--------------------|
| Fonctionnement | Wastegate |
| Commande | pneumatique |
| Restriction du fabricant | GARRETT |
| Type de turbo | Simple |
| Accessoires | sans joints |

PHOTOS




DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

| LANCIA | | |
|--|--------|-------------------|
| DEDRA (835) - 2.0 HF Integrale (835AP) | 169 ch | 11.1990 > 07.1994 |
| DEDRA (835) - 2.0 i.e. Turbo (835AR) | 162 ch | 04.1991 > 07.1999 |
| DEDRA (835) - 2.0 i.e. Turbo Integrale (835AO) | 165 ch | 05.1990 > 07.1994 |
| DEDRA (835) - 2.0 Turbo (835AQ) | 177 ch | 11.1990 > 06.1994 |
| DELTA (79-94) (831) - 2.0 HF Integrale (831AB.024S, 831AB.028) | 177 ch | 12.1986 > 12.1992 |

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.