

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	BW - KKK
Type de turbo	Simple
Accessoires	sans joints

PHOTOS



DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

OPEL		
ASTRA G (98-05) Cabriolet - 2.0 16V Turbo	200 ch	11.2002 > 10.2005
ASTRA G (98-05) Cabriolet - 2.0 OPC	192 ch	03.2002 > 10.2005
ASTRA G (98-05) Caravan (F35_) - 2.0 OPC	192 ch	09.2002 > 07.2004
	200 ch	11.2002 > 07.2004
ASTRA G (98-05) CC (F48_, F08_) - 2.0 OPC	192 ch	09.2002 > 01.2005
	200 ch	11.2002 > 01.2005
ASTRA G (98-05) Coupe (F07_) - 2.0 16V Turbo	190 ch	09.2000 > 08.2001
	192 ch	08.2001 > 05.2005
	200 ch	11.2002 > 05.2005
SPEEDSTER - 2.0 Turbo	200 ch	04.2003 >
ZAFIRA A (99-06) (F75_) - 2.0 OPC	192 ch	09.2001 > 06.2005
	200 ch	11.2002 > 06.2005

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.