

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	GARRETT
Type de turbo	Simple
Accessoires	avec joints

PHOTOS




DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

FIAT		
TEMPRA (159) - 1.9 TD (159.AQ)	80 ch	07.1992 > 02.1994
TEMPRA (159) - 1.9 TD (159.AI/AU/BI/CU)	90 ch	05.1990 > 08.1996
TEMPRA SW (159) - 1.9 TD (159.AI/AU/BI/CU)	90 ch	07.1991 > 02.1995
TEMPRA SW (159) - 1.9 TD (159.AQ)	80 ch	03.1992 > 06.1993
TIPO (88-95) (160) - 1.9 TD (160.AW)	80 ch	03.1992 > 06.1993
TIPO (88-95) (160) - 1.9 TD (160.AQ/AR/EI/EL/GL)	90 ch	09.1990 > 04.1995
LANCIA		
DEDRA SW (835) - 1.9 TDS (835EE, 835EF)	90 ch	07.1994 > 07.1999
DELTA (93-99) (836) - 1.9 TD (836AM, 836AN)	90 ch	10.1994 > 08.1999

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.