

## DONNEES TECHNIQUES

Fonctionnement	<b>Wastegate</b>
Commande	<b>pneumatique</b>
Restriction du fabricant	<b>GARRETT</b>
Type de turbo	<b>Simple</b>
Accessoires	<b>sans joints</b>

## PHOTOS



## DOCUMENTS

**BT-183** Instructions de montage turbos (AST)

## APPLICATIONS

<b>BMW</b>		
3 Series (90-99) (E36) - 325tds	143 ch	05.1993 > 12.1995
3 Series (90-99) Break/Touring (E36) - 325tds	143 ch	01.1995 > 12.1995
5 Series (88-96) (E34) - 525tds	143 ch	09.1991 > 09.1995
5 Series (88-96) Break/Touring (E34) - 525tds	143 ch	12.1991 > 01.1997

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.