

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	GARRETT
Type de turbo	Simple
Accessoires	sans joints

PHOTOS



DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

BMW		
3 Series (90-99) (E36) - 325td	115 ch	09.1991 > 12.1995
3 Series (90-99) (E36) - 325tds	143 ch	05.1993 > 02.1998
3 Series (90-99) Break/Touring (E36) - 325tds	143 ch	01.1995 > 10.1999
5 Series (88-96) (E34) - 525td	115 ch	04.1993 > 09.1995
5 Series (88-96) (E34) - 525tds	143 ch	09.1991 > 09.1995
5 Series (88-96) Break/Touring (E34) - 525td	115 ch	03.1993 > 01.1997
5 Series (95-03) (E39) - 525td	116 ch	01.1997 > 06.2003
5 Series (95-03) Break/Touring (E39) - 525tds	143 ch	03.1997 > 05.2004

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.