

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	GARRETT
Type de turbo	Simple
Accessoires	sans joints

PHOTOS



DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

CITROËN

XM (94-01) (Y4) - 2.1 TD 12V	109 ch	05.1994 > 10.2000
XM (94-01) (Y4) Break - 2.1 TD 12V	109 ch	05.1994 > 10.2000

FIAT

ULYSSE (220) - 2.1 TD	109 ch	03.1996 > 10.1999
-----------------------	--------	-------------------

LANCIA

ZETA (220) - 2.1 TD (220AJ5)	109 ch	05.1996 > 09.1999
------------------------------	--------	-------------------

PEUGEOT

806 (221) - 2.1 td 12V	109 ch	06.1996 > 08.1999
------------------------	--------	-------------------

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.