

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	GARRETT
Type de turbo	Simple
Accessoires	sans joints

PHOTOS



DOCUMENTS

BT-183 Instructions de montage turbos (AST)


APPLICATIONS

CITROËN

XM (89-94) (Y3) - 2.1 TD 12V	109 ch	05.1989 > 06.1994
XM (89-94) (Y3) Break - 2.1 TD 12V	109 ch	11.1991 > 04.1994
XM (94-01) (Y4) - 2.1 TD 12V	109 ch	05.1994 > 10.2000
XM (94-01) (Y4) Break - 2.1 TD 12V	109 ch	05.1994 > 10.2000

PEUGEOT

605 (6B) - 2.1 TD 12V	109 ch	08.1994 > 09.1999
605 (6B) - 2.1 Turbo Diesel	109 ch	06.1989 > 09.1999

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.