

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	BW - KKK
Type de turbo	Simple
Accessoires	sans joints
	Suralimentation à 2 Etages - Second Turbo

PHOTOS



DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

BMW		
3 Series (05-12) (E90) - 335d	286 ch	09.2006 >
3 Series (05-12) Break/Touring (E91) - 335d	286 ch	09.2006 >
3 Series (05-12) Coupé (E92) - 335d	286 ch	09.2006 >
5 Series (03-10) (E60) - 535d	286 ch	01.2007 >
5 Series (03-10) Break/Touring (E61) - 535d	286 ch	01.2007 >
6 Series (03-10) Cabriolet (E64) - 635d	286 ch	07.2007 >
X3 (03-10) (E83) - 3.0sd	286 ch	09.2006 >
X5 (07-13) (E70) - 3.0sd	286 ch	09.2007 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.