

DONNEES TECHNIQUES

Type de poulie	PVR6
Diamètre 1 [mm]	180
Diamètre intérieur [mm]	40
Hauteur [mm]	47

PHOTOS



DOCUMENTS


BT-114 Généralités sur les poulies damper

BT-180 Précautions de montage des poulies damper

APPLICATIONS

BMW		
1 Series (04-11) (E81, E87) - 116d	116 ch	09.2004 >
	116 ch	12.2008 > 09.2012
1 Series (04-11) (E81, E87) - 118d	122 ch	11.2003 > 09.2012
	122 ch	09.2004 >
	143 ch	11.2003 > 09.2012
	143 ch	04.2007 >
1 Series (04-11) (E81, E87) - 120d	163 ch	11.2003 > 09.2012
	163 ch	09.2004 >
	177 ch	11.2003 > 09.2012
	177 ch	03.2007 >
1 Series (04-11) Coupe (E82) - 118d	136 ch	09.2009 >
	143 ch	09.2009 >
1 Series (04-11) Coupe (E82) - 120d	177 ch	10.2007 >
1 Series (04-11) Cabriolet (E88) - 118d	143 ch	09.2008 >
1 Series (04-11) Cabriolet (E88) - 120d	177 ch	03.2008 >
	197 ch	03.2008 >
3 Series (05-12) (E90) - 316d	116 ch	07.2009 >
3 Series (05-12) (E90) - 318d	122 ch	09.2005 >
	136 ch	07.2007 >
	143 ch	09.2005 >
3 Series (05-12) (E90) - 320d	150 ch	09.2005 >
	163 ch	01.2005 >
	177 ch	09.2007 >
	184 ch	01.2010 >
3 Series (05-12) (E90) - 320d xDrive	163 ch	07.2008 > 12.2010
	177 ch	09.2008 >
	184 ch	01.2010 >
3 Series (05-12) (E90) - 320xd	177 ch	09.2007 >
3 Series (05-12) Break/Touring (E91) - 316d	116 ch	09.2009 >
3 Series (05-12) Break/Touring (E91) - 318d	122 ch	09.2005 >
	136 ch	07.2007 >
	143 ch	09.2007 >
3 Series (05-12) Break/Touring (E91) - 320d	163 ch	09.2005 >
	177 ch	09.2007 >
	184 ch	01.2010 >
3 Series (05-12) Break/Touring (E91) - 320d xDrive	163 ch	07.2009 >
	177 ch	09.2008 >
	184 ch	01.2010 >
3 Series (05-12) Break/Touring (E91) - 320xd	177 ch	09.2007 >
3 Series (05-12) Coupé (E92) - 320d	177 ch	03.2007 >
3 Series (05-12) Coupé (E92) - 320d xDrive	184 ch	01.2010 >
3 Series (05-12) Coupé (E92) - 320d	184 ch	01.2010 >
3 Series (05-12) Coupé (E92) - 320d xDrive	177 ch	09.2008 >
3 Series (05-12) Coupé (E92) - 320xd	177 ch	03.2007 >
	184 ch	01.2010 >
3 Series (05-12) Cabriolet (E93) - 320d	177 ch	03.2007 >
	184 ch	01.2010 >
5 Series (03-10) (E60) - 520d	163 ch	07.2005 >
	177 ch	09.2007 >

BMW		
5 Series (03-10) Break/Touring (E61) - 520d	150 ch	09.2005 >
	163 ch	07.2005 >
	177 ch	09.2007 >
X1 (09-15) (E84) - sDrive 18d	143 ch	10.2009 >
X1 (09-15) (E84) - sDrive 20d	177 ch	10.2009 >
X1 (09-15) (E84) - xDrive 18d	143 ch	10.2009 >
X1 (09-15) (E84) - xDrive 20d	177 ch	10.2009 >
X3 (03-10) (E83) - 2.0d	177 ch	09.2007 >
X3 (03-10) (E83) - xDrive 18d	143 ch	09.2008 >
X3 (03-10) (E83) - xDrive 20d	163 ch	09.2008 >
	177 ch	09.2008 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.