



Important - Please Read Before Installation

EN Mounting instructions

To fit the new pump, drill a hole in the original pulley to access the bolts of the front mounting bracket.

DE Montagehinweis

Um die neue Pumpe zu montieren, bohren Sie ein Loch in die Original-Riemenscheibe. Auf diese Weise erhalten Sie Zugang zu den Schrauben der vorderen Montagehalterung.

RO Instrucțiuni de montaj

Pentru a monta noua pompă, dați o gaură în fulia originală. În acest fel, veți avea acces la șuruburile suportului de fixare din față.

DA Monteringsanvisning

Bor et hul i den originale remskive for at montere den nye pumpe. På den måde får du adgang til skruerne på den forreste montageholder.



Disclaimer of Liability

The information contained on this leaflet ("Service") is for general information purposes only. The application of any GKN Automotive product subject to the Service must be performed by certified professionals. GKN Automotive assumes no responsibility for errors or omissions in the contents on the Service. In no event shall GKN Automotive be liable for any special, direct, indirect, consequential, or incidental damages or any damages whatsoever, whether in an action of contract, negligence or other tort, arising out of or in connection with the use of the Service or the contents of the Service. GKN Automotive reserves the right to make additions, deletions, or modification to the contents on the Service at any time without prior notice.