



Wichtiger Montagehinweis

STT Bremsleitungsverbinder



- Für 4,75 mm Kupfer-, Kupfer-Nickel und Stahl Bremsleitungen
- Doppelkonus-Schneidring
- Montage ohne Bördelung
- Keine Überwurfschrauben
- Drucktest über 600 Bar

Einbauempfehlung



SCHRITT 1

- **Bremsleitung durchtrennen und beide Endstücke säubern.**
- **Bremsleitung entsprechend Bild bis zum Anschlag einstecken**



SCHRITT 2

- **Überwurfmuttern per Hand festziehen.**
- **Mittelteil mit 11er Maulschlüssel festhalten**
- **Zum Abschluss beide Muttern jeweils eine $\frac{3}{4}$ Umdrehung anspannen.**





Important installation notice

STT Adapter, brake lines (Union Nut)



- Suitable for 4.75mm copper-, copper-nickel and steel brake lines
- Double-cone cutting ring
- Fitting without flanging
- No sleeve nuts
- -Pressure test above 600 bar

Fitting recommendation



Step 1

- Cut the brake line and clean both ends
- Push the brake line to the stop as shown on the picture



Step2

- Tighten the union nuts by hand
- Hold the middle part using an 11 mm open-end spanner
- Finally tighten both nuts with a three-quarter turn

