CREM ASS SIERRA (RACC BR)

Remanufactured

Core code : 55

FCDADA

3599771632154



TECHNICAL DATA

Operating Mode	**hydraulic**
Steering	**without tie rod end**
Distance of mounting bores [mm]	**400 mm**
for steering gear manufacturer	**ZF**
Axle Joint Thread Size	**M14x200**
Pressure Line Connection Thread Size	**Ø11mm**
Pressure Line Connection Thread Size	**Ø10mm**
Length [mm]	**1270 mm**
Height [mm]	**103 mm**
Hub Profile	**Cannelé avec guide**
Number of Teeth on input shaft	**40**
Mounting	**2 (Ø11mm)**

PICTURES











Before installation, compare the part received with the original part to ensure that the correct part number has been selected and can be installed on the vehicle. Failure to follow those, or the manufacturer, instructions will void the warranty.

FORD		
SIERRA (82-86) 3/5 portes (GBC) - 1.3	60 ch	08.1982 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 1.6	69 ch	10.1982 > 02.1987
	75 ch	08.1982 > 12.1986
	79 ch	08.1984 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 1.8	90 ch	10.1984 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.0	100 ch	10.1985 > 12.1986
	105 ch	08.1982 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.0 i	115 ch	03.1985 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.3	114 ch	08.1982 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.8 XR4i	143 ch	08.1982 > 12.1986
	146 ch	08.1982 > 12.1986
	150 ch	08.1982 > 12.1986
SIERRA (82-86) 3/5 portes (GBC) - 2.3 D	67 ch	08.1982 > 12.1986
SIERRA (82-86) Break (BNC) - 1.6	75 ch	08.1982 > 12.1986
SIERRA (82-86) Break (BNC) - 1.8	90 ch	10.1984 > 12.1986
SIERRA (82-86) Break (BNC) - 2.0	100 ch	10.1985 > 12.1986
	105 ch	08.1982 > 12.1986
	115 ch	03.1985 > 12.1986
SIERRA (82-86) Break (BNC) - 2.3	114 ch	08.1982 > 12.1986
SIERRA (82-86) Break (BNC) - 2.8 XR4i	143 ch	08.1982 > 12.1986
	146 ch	08.1982 > 12.1986
SIERRA (82-86) Break (BNC) - 2.3 D	67 ch	08.1982 > 12.1986
SIERRA (87-93) (GBG, GB4) - 1.6	72 ch	01.1988 > 02.1993
	75 ch	01.1987 > 02.1993
SIERRA (87-93) (GBG, GB4) - 1.6 i	80 ch	10.1989 > 02.1993
SIERRA (87-93) (GBG, GB4) - 1.8	87 ch	05.1988 > 02.1993
	80 ch	10.1987 > 09.1989
	90 ch	01.1987 > 05.1988
SIERRA (87-93) (GBG, GB4) - 2.0 i	100 ch	01.1987 > 12.1989
SIERRA (87-93) (GBG, GB4) - 2.0 i Cat	100 ch	01.1987 > 02.1993
SIERRA (87-93) (GBG, GB4) - 2.0	105 ch	01.1987 > 02.1993
SIERRA (87-93) (GBG, GB4) - 2.0 i	115 ch	01.1987 > 02.1993
SIERRA (87-93) (GBG, GB4) - 2.9 i	145 ch	08.1988 > 02.1993
	150 ch	08.1988 > 02.1993
SIERRA (87-93) (GBG, GB4) - 1.8 TD	75 ch	08.1988 > 02.1993
SIERRA (87-93) (GBG, GB4) - 2.3 D	67 ch	01.1987 > 09.1989
SIERRA (87-93) 3/5 portes (GBC, GBG) - 1.6	72 ch	01.1988 > 02.1993
	75 ch	01.1987 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 1.6 i	80 ch	10.1989 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 1.8	80 ch	10.1987 > 05.1988
	87 ch	05.1988 > 02.1993
	90 ch	01.1987 > 05.1988
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.0 i	100 ch	01.1987 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.0 i Cat	100 ch	01.1987 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.0	105 ch	01.1987 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.0 i	109 ch	06.1989 > 02.1993
	115 ch	01.1987 > 02.1993
	120 ch	06.1989 > 02.1993
	125 ch	06.1989 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.8 i	143 ch	01.1987 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.8	150 ch	03.1987 > 09.1989

FORD		
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.9 i	145 ch	08.1988 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 1.8 TD	75 ch	08.1988 > 02.1993
SIERRA (87-93) 3/5 portes (GBC, GBG) - 2.3 D	67 ch	01.1987 > 09.1989
SIERRA (87-93) Break (BNG) - 1.6	72 ch	01.1988 > 02.1993
	75 ch	01.1987 > 02.1993
SIERRA (87-93) Break (BNG) - 1.6 i	80 ch	10.1989 > 02.1993
SIERRA (87-93) Break (BNG) - 1.8	80 ch	10.1987 > 05.1988
	87 ch	05.1988 > 02.1993
	90 ch	01.1987 > 05.1988
SIERRA (87-93) Break (BNG) - 1.9	108 ch	10.1988 > 09.1991
SIERRA (87-93) Break (BNG) - 2.0 i	100 ch	01.1987 > 02.1993
SIERRA (87-93) Break (BNG) - 2.0 i Cat	100 ch	01.1987 > 02.1993
SIERRA (87-93) Break (BNG) - 2.0	105 ch	01.1987 > 02.1993
SIERRA (87-93) Break (BNG) - 2.0 i	115 ch	01.1987 > 02.1993
	120 ch	05.1989 > 02.1993
	125 ch	05.1989 > 02.1993
SIERRA (87-93) Break (BNG) - 2.8 i	143 ch	01.1987 > 02.1993
	146 ch	**01.1987 > 04.1989**
SIERRA (87-93) Break (BNG) - 2.9	145 ch	08.1988 > 02.1993
SIERRA (87-93) Break (BNG) - 2.9 i	150 ch	08.1988 > 02.1993
SIERRA (87-93) Break (BNG) - 1.8 TD	75 ch	08.1988 > 02.1993
SIERRA (87-93) Break (BNG) - 2.3 D	67 ch	01.1987 > 02.1993