

- Ⓓ Wechselintervall alle ...
- ⒼⒷ Replacement interval ...
- Ⓘ Sostituzione dopo ...
- Ⓕ Intervalle de remplacement ...
- Ⓔ Intervalle de cambio ...
- ⒶⓁ Vervanging elke ...

15.000 KM /

10.000 MI

- Ⓓ ... oder nach 1 Jahr
- ⒼⒷ ... or after 1 year
- Ⓘ ... or dopo 1 anno
- Ⓕ ... ou 1 fois par an
- Ⓔ ... o después de 1 ano
- ⒶⓁ ... of 1 keer per jaar

**Alfa Romeo 147** 05.00 →  
**Alfa Romeo 156 + Sportswagon** 01.02 →  
**Alfa Romeo GT** 04 →

21652352 / CC1202 / MC 595-2  
 80000375 / CP1202 / MP 095-2

### Einbauanleitung

Innenraumfilter

### Fitting instructions

Cabin air filter

### Istruzioni di montaggio

Filtro abitacolo

### Notice de montage

Filtre d'habitacle

### Instrucciones de montaje

Filtro de habitáculo

### Inbouwhandleiding

Interieurfilter

Alfa Romeo 147, GT

Alfa Romeo 156 + Sportswagon

