



# EASY SET


Installation instructions  
Instruções de montagem  
Instructions de montage

Instrucciones de montaje  
Инструкция по установке



Istruzioni di montaggio  
Montageanleitung





## 22/19mm





## PINCH



## 22mm




## 19mm





!Re-attachable if miscut.  
!Weider anbringbar bei Fehlschnitt.  
!Reattachable si mal coupée.  
!Reutilizable si fue cortado.  
!Riutilizzare se tagliati  
!Reconectável si foi cortado.



!Возможна повторная установка при ошибочном удалении



## INSERT LOCK



## MULTI HOOK



Adaptor configuration may vary based on product and sales region.  
See detailed adaptors on the packaging.

© HELLA GmbH & Co. KGaA  
Rixbecker Straße 75  
59552 Lippstadt/Germany  
www.hella.com  
460.576-84 /05.21





# EASY SET

Installation instructions    Instrucciones de montaje    Istruzioni di montaggio  
Instruções de montagem    Инструкция по установке    Montageanleitung  
Instructions de montage

3C(+)-3C-B





With 3C-B



3C(-)-3C-B




Remove 3C-B





3H-7

PUSH BUTTON  
15.5mm



3T

PUSH BUTTON  
FZ



3U

LIFT & SLIDE

