

DONNEES TECHNIQUES

Fonctionnement	Wastegate
Commande	pneumatique
Restriction du fabricant	BW - KKK
Type de turbo	Simple
Accessoires	avec joints

PHOTOS




DOCUMENTS

BT-183 Instructions de montage turbos (AST)

APPLICATIONS

IVECO		
DAILY (00-06) - 2.8 29 L 11	105 ch	05.1999 >
DAILY (00-06) - 2.8 29 L 11 V	106 ch	05.1999 >
DAILY (00-06) - 2.8 29 L 13	125 ch	05.2001 >
	125 ch	11.2001 >
DAILY (00-06) - 2.8 35 C/S 11	106 ch	05.1999 >
DAILY (00-06) - 2.8 35 C/S 11 V	106 ch	05.1999 >
DAILY (00-06) - 2.8 35 C/S 13	125 ch	05.1999 >
DAILY (00-06) - 2.8 35 C/S 13 V	125 ch	05.1999 >
DAILY (00-06) - 2.8 50 C 11	106 ch	05.1999 >
	106 ch	05.1999 >
DAILY (00-06) - 2.8 50 C 13	125 ch	05.1999 >
	125 ch	05.1999 >

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.