

DONNEES TECHNIQUES

Diamètre 1 [mm]	48
matière	caoutchouc
Diamètre 2 [mm]	14
Hauteur [mm]	158


PHOTOS



APPLICATIONS

HYUNDAI		
SONATA (88-94) (Y-2) - 1.8 i	95 ch	09.1988 > 10.1993
SONATA (88-94) (Y-2) - 2.0 i	101 ch	09.1988 > 08.1991
	109 ch	01.1991 > 10.1993
SONATA (88-94) (Y-2) - 2.0 i 16V	130 ch	01.1991 > 10.1993
SONATA (88-94) (Y-2) - 2.4 i	113 ch	09.1988 > 08.1991
SONATA (88-94) (Y-2) - 3.0 i V6	145 ch	01.1991 > 10.1993
SONATA (95-98) (Y-3) - 1.8 GLS	86 ch	07.1996 > 05.1998
SONATA (95-98) (Y-3) - 1.8 i	98 ch	05.1993 > 06.1998
SONATA (95-98) (Y-3) - 2.0	131 ch	07.1994 > 10.1994
SONATA (95-98) (Y-3) - 2.0 i	95 ch	08.1996 > 06.1998
	105 ch	06.1994 > 08.1996
SONATA (95-98) (Y-3) - 2.0 i 16V	125 ch	06.1996 > 06.1998
	139 ch	05.1993 > 06.1998
SONATA (95-98) (Y-3) - 3.0 i V6	146 ch	05.1993 > 06.1998
SONATA (99-01) (EF) - 2.0 16V	136 ch	06.1998 > 10.2001
SONATA (99-01) (EF) - 2.4 16V	143 ch	03.1998 > 10.2001
SONATA (99-01) (EF) - 2.5 V6 24V	160 ch	06.1998 > 10.2001

OPEL		
VECTRA B (36_) - 1.6 GL	82 ch	09.1995 > 08.1996
VECTRA B (36_) - 1.6 i	75 ch	10.1995 > 04.2002
	75 ch	10.1995 > 04.2002
VECTRA B (36_) - 1.6 i 16V	100 ch	10.1995 > 04.2002
VECTRA B (36_) - 1.7 TD	82 ch	10.1995 > 12.1998
VECTRA B (36_) - 1.8 i 16V	115 ch	10.1995 > 09.2000
	125 ch	09.2000 > 04.2002
VECTRA B (36_) - 2.0 DI 16V	82 ch	11.1996 > 04.2002
VECTRA B (36_) - 2.0 DTI 16V	101 ch	06.1997 > 04.2002
VECTRA B (36_) - 2.0 i	112 ch	10.1995 > 04.2002
VECTRA B (36_) - 2.0 i 16V	136 ch	01.1998 > 09.2000
VECTRA B (36_) - 2.2 DTI 16V	125 ch	09.2000 > 04.2002
VECTRA B (36_) - 2.2 i 16V	147 ch	09.2000 > 04.2002
VECTRA B (36_) - 2.5 i V6	170 ch	01.1998 > 09.2000
VECTRA B (36_) - 2.6 i V6	170 ch	09.2000 > 04.2002
VECTRA B (36_) - i 500 2.5	194 ch	05.1998 > 09.2000
VECTRA B Caravan (31_) - 1.6 i	75 ch	11.1996 > 06.2000
	75 ch	11.1996 > 06.2000
VECTRA B Caravan (31_) - 1.6 i 16V	100 ch	11.1996 > 07.2002
VECTRA B Caravan (31_) - 1.7 TD	82 ch	11.1996 > 12.1997
VECTRA B Caravan (31_) - 1.8 i 16V	115 ch	11.1996 > 09.2000
	125 ch	09.2000 > 07.2003
VECTRA B Caravan (31_) - 2.0 DI 16V	82 ch	11.1996 > 06.2000
VECTRA B Caravan (31_) - 2.0 DTI 16V	101 ch	06.1997 > 07.2003
VECTRA B Caravan (31_) - 2.0 i	112 ch	11.1996 > 02.2002
VECTRA B Caravan (31_) - 2.0 i 16V	136 ch	01.1998 > 09.2000
VECTRA B Caravan (31_) - 2.2 DTI 16V	125 ch	09.2000 > 07.2003
VECTRA B Caravan (31_) - 2.2 i 16V	147 ch	09.2000 > 07.2003
VECTRA B Caravan (31_) - 2.5 i V6	170 ch	01.1998 > 09.2000
VECTRA B Caravan (31_) - 2.6 i V6	170 ch	09.2000 > 07.2003
VECTRA B Caravan (31_) - i 500 2.5	194 ch	05.1998 > 09.2000
VECTRA B CC (38_) - 1.6 i	75 ch	10.1995 > 07.2003
	75 ch	10.1995 > 07.2003
VECTRA B CC (38_) - 1.6 i 16V	101 ch	10.1995 > 07.2002
VECTRA B CC (38_) - 1.7 TD	82 ch	10.1995 > 12.1998
VECTRA B CC (38_) - 1.8 i 16V	116 ch	10.1995 > 09.2000
	125 ch	09.2000 > 07.2003
VECTRA B CC (38_) - 2.0 DI 16V	82 ch	11.1996 > 06.2000
VECTRA B CC (38_) - 2.0 DTI 16V	101 ch	06.1997 > 07.2003
VECTRA B CC (38_) - 2.0 i	112 ch	10.1995 > 02.2002
VECTRA B CC (38_) - 2.0 i 16V	136 ch	01.1998 > 09.2000
VECTRA B CC (38_) - 2.2 DTI 16V	125 ch	09.2000 > 07.2003
VECTRA B CC (38_) - 2.2 i 16V	147 ch	09.2000 > 07.2003
VECTRA B CC (38_) - 2.5 i V6	170 ch	01.1998 > 09.2000
VECTRA B CC (38_) - 2.6 i V6	170 ch	09.2000 > 07.2003

 Avant montage, comparez la pièce reçue à celle d'origine afin de vérifier que la bonne pièce a été choisie et peut être montée sur le véhicule. Le non-respect de cette consigne ou des instructions de montage annule la garantie.